

# TriSwivel II

| Diagram | Description                             | Part #   |
|---------|---|----------|
| 1       | Scorehard holder                        | BBP21250 |
| 2       | Umbrella Holder Knob                    | BBP17703 |
| 3       | Upper bag bracket complete assembly     | BBP14101 |
| 3.1     | Upper Bracket Wing Right                | BBP14375 |
| 3.2     | Upper Bracket Wing Left                 | BBP14360 |
| 4       | Umbrella Holder                         | BBP17702 |
| 5       | Bag                                     | BBP15305 |
| 6       | Rear Wheel                              | BBP39585 |
| 7       | Upper Bag Strap                         | BBP46250 |
| 8       | Wheel Knuckle - Right                   | BBP17200 |
| 9       | Wheel strut wide LFT (3 hole)           | BBP08035 |
| 10      | Wheel strut wide RHT (3 hole)           | BBP08055 |
| 11      | Wheel strut narrow (LFT or Rght side)   | BBP08120 |
| 12      | Brake Cable                             | BBP60260 |
| 13      | Drag Link (LFT or RHT)                  | BBP31250 |
| 14      | Scorecard holder cover                  | BBP21218 |
| 15      | Support Cable                           | BBP33295 |
| 16      | Wheel knuckle - Left                    | BBP17201 |
| 17      | Main folding release lever and hardware | BBP11150 |
| 18      | Handle Adjustment Lever                 | BBP25050 |
| 19      | Lower bag strap                         | BBP46050 |
| 20      | Front Swivel Mount                      | BBP58220 |
| 21      | Fork                                    | BBP58200 |
| 22      | Swivel lock CABLE                       | BBP19125 |
| 23      | Front Wheel                             | BBP61097 |

|  |                          |               |
|--|--------------------------|---------------|
|  | Triswivel 2 Hardware Kit | BBP71370-HDWR |
|--|--------------------------|---------------|

